

Fast readout of a carbon nanotube mechanical resonator

Harold Meerwaldt

Ben Schneider

Vibhor Singh

Scott Johnston

Raymond Schouten

Herre van der Zant

Gary Steele



Conclusion


We have read out the mechanical motion of a carbon nanotube with submicrosecond time resolution.

Motivation: damping measurements

ringdown measurement

$$Q_{\text{ringdown}} = \omega_0 T_{\text{decay}}/2$$


mechanical amplitude



not yet done in CNTs
due to bandwidth limitations

spectral measurement

$$Q_{\text{spectral}} = \omega_0 / \omega_{\text{FWHM}}$$




standard for CNTs


Quality factor contributions

energy relaxation

mechanical amplitude




$$Q_{\text{spectral}} = Q_{\text{ringdown}}$$




spectral broadening/excess phase noise


mechanical amplitude




$$Q_{\text{spectral}} < Q_{\text{ringdown}}$$



Spectral broadening in CNTs




Witkamp et al., NanoLett 2006



Barnard et al., PNAS 2012


- Low Q @ RT
- Mode coupling + thermal motion \rightarrow spectral broadening ($Q_{\text{spectral}} < Q_{\text{ringdown}}?$)

High-bandwidth measurement





- mechanical (and electrical) mixing $G^{\omega_d} \cdot V_b^{\omega_d + \Delta\omega} \Rightarrow I_{mix}^{\Delta\omega}$
- a close-proximity amplifier
 - high-impedance
 - low power → cryogenically compatible

Close-proximity HEMT amplifier




Device characteristics


- length: 700 nm
- separated ~ 200 nm from gate
- gate-dependent conductance



Amplifier characterization




A CNT as a high-frequency mixer



- Typically: intermediate frequency $\sim 10 \text{ kHz}$


Sazonova et al.
Nature, 2004

Fast readout of mechanical motion



- room-temperature vacuum
- timeconstant = 780 ns (typically: 100 ms)
- measurement time: 175 points \times 780 ns \sim 0.1 ms!

Mixing signal in the time domain




- decay time \sim time constant
- upper limit for $Q_{\text{ringdown}} < 490$, at room temperature ($Q_{\text{spectral}} \sim 40$)




Conclusions

- We have used a close-proximity, high-impedance amplifier to measure a carbon nanotube resonator.
- We can measure five orders of magnitude faster than ever done, arriving at submicrosecond time resolution.
- We get an upper bound for room-temperature energy relaxation of $Q_{\text{ringdown}} < 490$.
- Next step: cryogenic measurements (higher Q)

Mechanical lineshape




■ Mixing \rightarrow Fano lineshape



Witkamp et al., NanoLett 2006

■ Strong driving \rightarrow
Nonlinear/Duffing lineshape



Hüttel et al., NanoLett 2009

Quadratures of lockin signal

